



S&G ELECTRONIC COMBINATION LOCK 6124-120

OPERATION INSTRUCTIONS

1. HOW TO OPEN THE DOOR

- If your safe is supplied with keylock also make sure keylock is unlocked.
- Press your *6-digit* code and then press **#**
- Turn the knob.
- Door is open.

2. HOW TO LOCK THE DOOR

- Close the door.
- Turn knob at the locked position. **S&G** combination lock automatically locks the bolts.
- If your safe is supplied with keylock also make sure to lock and remove key.

3. HOW TO SET A NEW CODE

- Your S&G combination lock is supplied with the initial **CODE 123456**
- To set a new code enter:
 - 22*** Old 6-digit code **#**
 - New 6-digit code **#**
 - New 6-digit code **#**
- Lock is now programmed to open with the new code.